Smart Life APP & Alexa User Manual

Thanks for Choosing us!


NO.1 Downrod “Smart Life ” and “ Amazon Alexa ” APP


Seach and downrod “ **Smart Life** ” and “ **Amazon Alexa** ” in application markets or scan the QR code below to downrod the APP.

Smart life

Amazon Alexa

NO.2 Registration / Login







“Smart Life ” Regstration

If you don’t have an account, you can sign up using an email address, or Google (iPhone) account.

NO.2 Registration / Login







“Amazon Alexa ” Registration /Login

You can log in or register using your number or an email address.

NO.3 Connecting the Ceiling Fan to the “ **Smart Life** ” APP

Method 1: Automatic Connection
Tap the “+” located in the top-right corner → “**Add Device**”





Enable 2.4G Wi-Fi and Bluetooth


(Ensure the fan is installed within close proximity to the 2.4G Wi-Fi signal source.)


NO.3 Connecting the Ceiling Fan to the “ Smart Life ” APP


Press and hold the remote control “4H” button until the ceiling fan emits a continuous breeze sound, indicating that it is in pairing mode.

When the device "**Ceiling Fan with Light**" appears automatically, tap on it → Enter the Wi-Fi password → Wait for 2-3 seconds → Tap "**Done**" to complete the connection successfully












Press and hold the button with the WiFi symbol on the remote control.


When the device labeled “ **FAN-LIGHT 1** ” pops up, click “ **Add** ” → Connect to WiFi → Wait a few seconds → Click “ **Done** ” to complete the connection
















NO.3 Connecting the Ceiling Fan to the “ Smart Life ” APP

Method 2: Manual Pairing

Tap the "**+**" → **Add Device** " → " **Small Home Appliances**" → " **Fan (Wi-Fi).**"









If automatic pairing is not possible, you can choose manual pairing to connect.


When the "**Select 2.4GHz Wi-Fi Network and enter password**" window appears, tap "**Next**" and confirm again.






NO.3 Connecting the Ceiling Fan to the “ Smart Life ” APP


Press and hold the **"4H"** button on the remote control until the ceiling fan emits a slow, continuous breeze sound → confirm in the app by selecting **"Confirm the indicator is blinking"** → **"Blink Slowly."**







Tips: If the fan emits a rapid breeze sound → select **"Blink Quickly"** in the application.

The application will detect the **Smart Life** hotspot automatically → Tap "**Join**" → Proceeding to "**Initialize the device**" indicates a successful connection









Tips: If neither Method 1 nor Method 2 can connect the ceiling fan, it is possible that the fan is too far from the Wi-Fi signal source. You can try installing the fan within 30M of the Wi-Fi source and attempt the connection again.
If the connection still fails after moving closer to the signal source, please contact us to replace the remote control and receiver!

NO.4 Connecting the Ceiling Fan to “ Amazon Alexa ”


Method 1: Automatic connection to “**Amazon Alexa**”


Tap the "**Alexa**" feature in the "**Smart Life**" APP →"**Link to Amazon Alexa**"






Tap "**Re-link**" → "**Link**" → "**Done**”









NO.4 Connecting the Ceiling Fan to “ Amazon Alexa ”

Open Amazon Alexa, and if this page appears, the connection is successful.




Tips:Tap "**Device Control**" to view Alexa commands.




NO.4 Connecting the Ceiling Fan to “ Amazon Alexa ”

Method 2: Manual Connection via the **Amazon Alexa** APP

Tap the " **+** " in the top right corner → " **Add Device** " → " **Fan** " → " **Other** " → " **Wi-Fi** " → wait for 1 second for the connectable device to appear automatically → Tap " **Next** "




Add the “ **fan** “ → Specify its installation location → Repeat this process to add the “ **light** ” → Tap **"Done"**



NO.4 Connecting the Ceiling Fan to “ Amazon Alexa ”

If this page appears, the connection is successful



If “ **Amazon Alexa** ” does not have a ceiling fan device, please check if you are connected to “ **Smart Life** ”

Tips: If Alexa does not respond to your commands, please check whether the device name in Amazon Alexa matches the name you are using in your voice commands to Alexa.

Use Alexa voice commands to control device

Turn Fan and Light On/off:

“Alexa,turn on / off the [device name] fan / light. ”

Set Fan Mode

“ Alexa,set the [device name] to Normal / Sleep / Natural mode. ”

Change Fan Rotation Direction

“ Alexa,set the <mode name>on the<device name> to<mode value>.”

Adjust Fan Speed

“ Alexa,set the [device name] fan speed to 1-6.”

Adjust Light Brightness

“Alexa,set the [device name] light to [percentage] %.”

封底